

■ MAX FIRE Jukebox

TV & DISPLAY FITTINGS



2
years warranty



→ Better games through innovation!


TAB
AUSTRIA
www.tab.at

"LEONA LEWIS - SPIRIT" NOW IN YOUR MUSICSTORE AND AS DOWNLOAD AVAILABLE
(c) Sony BMG Music Entertainment (UK) Limited

Connect second monitor for playing videos

Optional: DVI, SVideo, RGB, HDMI


You have different options to connect your second monitor.

Look first which connection your monitor has:

- HDMI – connection
- DVI – connection
- RGB – connection
- SVideo – connection
- Chinch – connection

The following order (start with the best quality) correspond also the quality of the picture (for example if you have a DVI and a RGB connection on the monitor, please choose the better one → DVI). HDMI is the best connection, Chinch is the worst connection.

Since version 1.61 all of the 5 types work. By older versions the HDMI connection doesn't work. When you want to connect a purely digital TV and using a RGB connection, then maybe the monitor use a DDC signal. In this situation, please remove the pin 15 from the RGB output. After this it will work without any problems.




On the RGB connection there is the intern LCD.
 For DVI and SVideo there are the following options:

DVI to RGB (1), SVideo to Chinch (2), DVI to HDMI (3)




Wise:



Switch the Max Fire Jukebox off and plug the adapter (if it is necessary) on the port. Then plug the cable for the signal on the adapter or on the port and put the cable out on the backside off the Max Fire Jukebox. Plug the cable on the extern monitor and switch the Max Fire Jukebox on again.



Adapter 3



Adapter 1

Quality

HDMI	++++
DVI	++
RGB	0
SVIDEO	--
CHINCH	----

TV-Set

