

# *Technical Information*

➔ Better games through innovation!

[www.tab.at](http://www.tab.at)

## *AT & ATX Jumper settings* *QDI mainboard*

TAB-Austria Industrie- und Unterhaltungselektronik GmbH & CoKG

Haider Strasse 40, A-4052 Ansfelden

Tel.+43 (0)7229/78 040-0\*, Fax +43 (0)7229/78 660, e-mail: [sales@tab.at](mailto:sales@tab.at)

Hotline: +43 (0)7229/78 040-250, e-mail: [hotline@tab.at](mailto:hotline@tab.at)






To use the QDI motherboard with AT & ATX power supplies you can set jumpers on the motherboard.

On **picture 1** you can see where the jumpers on the motherboard are.

On **picture 2** you can see how to set the jumpers to work with AT & ATX power supplies.

### Picture 1






## Picture 2

### J\_ATX\_AT

If the jumper J\_ATX\_AT is set as closed, the mainboard use AT power; otherwise, the ATX power is supplied.



### J3\_3V1, J3\_3V2

